

Alvasys automation AG


YPC-WD

Anleitung Android 12 Touch Panel

Inhalt

IP Adresse ändern	3
Diverse Einstellungen	8
Toolbar.....	9
Start URL ändern	10
Passwort / PIN ändern	11
Bildschirmschoner Zeit.....	12
Mehrere Controller auf einem Display	13

Start Bildschirm



Start URL: IP Adresse des Controllers eingeben. (Wenn der Controller die Adresse <http://192.168.1.140> hat, muss zusätzlich ein / angefügt werden. (<http://192.168.1.140/>).


Dies muss nur bei genau dieser kombination gemacht werden ansonsten nicht

START USING ALVASYS KB: Den Kiosk-Modus starten


Alle anderen Einstellungen können so belassen werden und/oder im Nachhinein angepasst werden.



IP Adresse ändern

WICHTIG: Nur die rechte Netzwerkbuche (sicht von vorne) kann auf eine statische IP-Adresse gesetzt werden. Die linke ist immer auf DHCP eingestellt.




- Um in die Einstellungen zu gelangen, vom linken Bildschirmrand zur Mitte wischen.
- **Passwort: 1234**





- Von der Mitte aus nach oben wischen und Settings anklicken.





Ethernet

MAC
50:3e:16:ec:0e:0e

IP Address

Netmask

Gateway

DNS1

DNS2

Ethernet IP Mode
DHCP

Network & internet

Internet

SMS

IP mode


Static

IPv6 & tethering


Ethernet IP Mode

Static

DHCP




Wichtig: Alle Einstellungen müssen neu eingegeben werden (Auch wenn schon etwas drin steht). Erst wenn alle Eingaben gemacht wurden, kann man auf CONNECT drücken.




- Zurück zum Homescreen und auf das Alvasys Kiosk Browser app drücken.



Diverse Einstellungen



- Um in die Einstellungen zu gelangen, vom linken Bildschirmrand zur Mitte wischen.
- **Passwort: 1234**





Toolbar



Wichtigste Einstellungen

- Show Action Bar → Deaktivieren und aktivieren der Toolbar
- Action Bar Title → Einstellung der Überschrift

Start URL ändern



Passwort / PIN ändern

← Settings

🔍 Search in Settings

⚠️ Kiosk Mode protection can have some gaps in Android 12+. [Check FAQ!](#)

⚠️ For a better status bar and power button protection we recommend device provisioning. [Check our website!](#)

Advanced Web Settings
Web automation, JavaScript interface, QR scanner, keyboard, cookies, localhost, HTTP header, web filter, SSL, client CA, caching, debugging, user agent etc.

Universal Launcher
Start other apps and give them full kiosk protection, seamlessly mix apps, files and web bookmarks, start apps on Alvasys KB start

Toolbars and Appearance
Fullscreen mode, customize action bar, address bar, progress bar, tabs, select colors for the web browser and launcher

Screensaver (PLUS)
Play videos, slideshows or websites when device is idle or run Android Screen Saver

Device Management
Keep screen on, turn off on timer, unlock screen, screen orientation and brightness, start on boot, BT/Wifi, content sync

Power Settings
Scheduled sleep/wakeup, sleep on power connect/disconnect, wakelocks, battery warning

Kiosk Mode (PLUS)
Lockdown device, prevent from accessing other apps, settings or buttons, set PIN, single app mode

← Kiosk Mode (PLUS)

Kiosk Mode (PLUS)

Enable Kiosk Mode
Lockdown device with exit gesture and PIN

Kiosk Exit Gesture
Select the gesture to show the PIN dialog



Kiosk Mode PIN
PIN needed to exit the Kiosk Mode, default: 1234

Wifi/Settings PIN
Set a special PIN for wifi or settings access only


Disable Status Bar
Lock status bar and system settings access, read FAQ for Android 12+

Disable Volume Buttons
Lock volume level in Kiosk Mode

Bildschirmschoner Zeit



Hinweis: Sollte der Bildschirmschoner nicht aktiviert werden, muss die Notification auf «mute» gestellt werden.



Mehrere Controller auf einem Display

← Settings

🔍 Search in Settings

⚠️ Kiosk Mode protection can have some gaps in Android 12+. [Check FAQ!](#)

⚠️ For a better status bar and power button protection we recommend device provisioning. [Check our website!](#)

Web Content Settings
Start URL, HTML features, file upload, whitelist/blacklist, PDF, video, other contents, web overlay, custom error URL etc.

Web Browsing Settings
Pull-to-refresh, navigation options, click sound, back button, swipe tabs, search provider, NFC tags etc.

Web Zoom and Scaling
Enable zooming, initial page/text scaling, overview mode, wide viewport, desktop mode

Web Auto Reload
Reload Start URL or current page on idle, page error, screen on, network/internet reconnect, purge cache, cookies etc.

Advanced Web Settings
Web automation, JavaScript interface, QR scanner, keyboard, cookies, localhost, HTTP header, web filter, SSL, client CA, caching, debugging, use

Universal Launcher
Start other apps and give them full kiosk protection, seamlessly mix apps, files and web bookmarks, start apps on Alvasys KB start

← Universal Launcher

Universal Launcher

Select Items to Show
Select apps, files or web shortcuts to show on the launcher

Show Launcher on Start
Always show the launcher instead of Start URL, otherwise use fully://launcher to show it

Launcher Background Color
Select background color for the launcher

Launcher Text Color
Select app label color for the launcher


Launcher Background Image URL
Load launcher background image from this URL (or file)

Launche
Set page:

Inject HT

ADD APPLICATION **ADD URL** ADD FILE

Alle Controller die angezeigt werden sollen über « ADD URL» hinzufügen



- Zurück und die Option « Show Launcher on Start» auswählen

